

Assembly Language for Intel-Based Computers, 4<sup>th</sup> Edition  
Kip R. Irvine

Chapter 1: Basic Concepts

Slides prepared by Kip R. Irvine  
Revision date: 09/15/2002

- [Chapter corrections](#) (Web) [Assembly language sources](#) (Web)
- [Printing a slide show](#)

(c) Pearson Education, 2002. All rights reserved. You may modify and copy this slide show for your personal use, or for use in the classroom, as long as this copyright statement, the author's name, and the title are not changed.

---

---

---

---

---

---

---

---

Chapter Overview

- Welcome to Assembly Language
- Virtual Machine Concept
- Data Representation
- Boolean Operations

Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

2

---

---

---

---

---

---

---

---

Welcome to Assembly Language

- Some Good Questions to Ask
- Assembly Language Applications

Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

3

---

---

---

---

---

---

---

---

## Some Good Questions to Ask

- Why am I taking this course (reading this book)?
- What background should I have?
- What is an assembler?
- What hardware/software do I need?
- What types of programs will I create?
- What do I get with this book?
- What will I learn?

---

---

---

---

---

---

---

---

## Welcome to Assembly Language (cont)

- How does assembly language (AL) relate to machine language?
- How do C++ and Java relate to AL?
- Is AL portable?
- Why learn AL?

---

---

---

---

---

---

---

---

## Assembly Language Applications

- Some representative types of applications:
  - Business application for single platform
  - Hardware device driver
  - Business application for multiple platforms
  - Embedded systems & computer games

(see next panel)

---

---

---

---

---

---

---

---

## Comparing ASM to High-Level Languages


Type of Application	High-Level Languages	Assembly Language
Business application software, written for single platform, medium to large size.	Formal structures make it easy to organize and maintain large sections of code.	Minimal formal structure, so one must be impressed by programmers who have varying levels of experience. This leads to difficulties maintaining existing code.
Hardware device driver.	Language may not provide for direct hardware access. Even if it does, awkward coding techniques must often be used, resulting in maintenance difficulties.	Hardware access is straightforward and simple. Easy to maintain when programs are short and well documented.
Business application written for multiple platforms (different operating systems).	Usually very portable. The source code can be recompiled on each target operating system with minimal changes.	Must be coded separately for each platform, often using an assembler with a different syntax. Difficult to maintain.
Embedded systems and computer games requiring direct hardware access.	Produces too much executable code, and may not run efficiently.	Ideal, because the executable code is small and runs quickly.

## Virtual Machine Concept

- Virtual Machines
- Specific Machine Levels

## Virtual Machines

- Tanenbaum: Virtual machine concept
- Programming Language analogy:
  - Each computer has a native machine language (language L0) that runs directly on its hardware
  - A more human-friendly language is usually constructed above machine language, called Language L1
- Programs written in L1 can run two different ways:
  - **Interpretation** – L0 program interprets and executes L1 instructions one by one
  - **Translation** – L1 program is completely translated into an L0 program, which then runs on the computer hardware



---

---

---


---

---

---

---

---



---

---

---

---

---

---

---

---

### High-Level Language

- Level 5
- Application-oriented languages
  - C++, Java, Pascal, Visual Basic . . .
- Programs compile into assembly language (Level 4)

Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

12

---

---

---

---

---

---

---

---

## Assembly Language

- Level 4
- Instruction mnemonics that have a one-to-one correspondence to machine language
- Calls functions written at the operating system level (Level 3)
- Programs are translated into machine language (Level 2)

Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

13

---

---

---

---

---

---

---

---

## Operating System

- Level 3
- Provides services to Level 4 programs
- Translated and run at the instruction set architecture level (Level 2)

Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

14

---

---

---

---

---

---

---

---

## Instruction Set Architecture

- Level 2
- Also known as conventional machine language
- Executed by Level 1 (microarchitecture) program

Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

15

---

---

---

---

---

---

---

---

## Microarchitecture

- Level 1
- Interprets conventional machine instructions (Level 2)
- Executed by digital hardware (Level 0)

---

---

---

---

---

---

---

---

## Digital Logic

- Level 0
- CPU, constructed from digital logic gates
- System bus
- Memory
- Implemented using bipolar transistors

next: Data Representation

---

---

---

---

---

---

---

---

## Data Representation

- Binary Numbers
  - Translating between binary and decimal
- Binary Addition
- Integer Storage Sizes
- Hexadecimal Integers
  - Translating between decimal and hexadecimal
  - Hexadecimal subtraction
- Signed Integers
  - Binary subtraction
- Character Storage

---

---

---

---

---

---

---

---

# Binary Numbers

- Digits are 1 and 0
  - 1 = true
  - 0 = false
- MSB – most significant bit
- LSB – least significant bit

- Bit numbering:

MSB LSB

1 0 1 1 0 0 1 0 1 0 0 1 1 1 0 0

15 0

---

---

---

---

---

---

# Binary Numbers

- Each digit (bit) is either 1 or 0
- Each bit represents a power of 2:

1 1 1 1 1 1 1 1

$2^7$   $2^6$   $2^5$   $2^4$   $2^3$   $2^2$   $2^1$   $2^0$

Every binary number is a sum of powers of 2

Table 1-3 Binary Bit Position Values.

2 <sup>n</sup>	Decimal Value	2 <sup>n</sup>	Decimal Value
2 <sup>0</sup>	1	2 <sup>8</sup>	256
2 <sup>1</sup>	2	2 <sup>9</sup>	512
2 <sup>2</sup>	4	2 <sup>10</sup>	1024
2 <sup>3</sup>	8	2 <sup>11</sup>	2048
2 <sup>4</sup>	16	2 <sup>12</sup>	4096
2 <sup>5</sup>	32	2 <sup>13</sup>	8192
2 <sup>6</sup>	64	2 <sup>14</sup>	16384
2 <sup>7</sup>	128	2 <sup>15</sup>	32768

---

---

---

---

---

---

## Translating Binary to Decimal

Weighted positional notation shows how to calculate the decimal value of each binary bit:

$$dec = (D_{n-1} \times 2^{n-1}) + (D_{n-2} \times 2^{n-2}) + \dots + (D_1 \times 2^1) + (D_0 \times 2^0)$$

D = binary digit

binary 00001001 = decimal 9:

$$(1 \times 2^3) + (1 \times 2^0) = 9$$

---

---

---

---

---

---

## Translating Unsigned Decimal to Binary

- Repeatedly divide the decimal integer by 2. Each remainder is a binary digit in the translated value:

Division	Quotient	Remainder
37 / 2	18	1
18 / 2	9	0
9 / 2	4	1
4 / 2	2	0
2 / 2	1	0
1 / 2	0	1

37 = 100101

Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

22

---

---

---

---

---

---

---

---

---

---

## Binary Addition

- Starting with the LSB, add each pair of digits, include the carry if present.

carry: 1							
0	0	0	0	0	1	0	0
+	0	0	0	0	0	1	1
0	0	0	0	1	0	1	1
bit position: 7 6 5 4 3 2 1 0							

Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

23

---

---

---

---

---

---

---

---

---

---

## Integer Storage Sizes

Standard sizes:

byte	8
word	16
doubleword	32
quadword	64

Table 1-4 Ranges of Unsigned Integers.

Storage Type	Range (low-high)	Powers of 2
Unsigned byte	0 to 255	0 to ( $2^8 - 1$ )
Unsigned word	0 to 65,535	0 to ( $2^{16} - 1$ )
Unsigned doubleword	0 to 4,294,967,295	0 to ( $2^{32} - 1$ )
Unsigned quadword	0 to 18,446,744,073,709,551,615	0 to ( $2^{64} - 1$ )

What is the largest unsigned integer that may be stored in 20 bits?

Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

24

---

---

---

---

---

---

---

---

---

---



## Hexadecimal Integers

Binary values are represented in hexadecimal.

**Table 1-5** Binary, Decimal, and Hexadecimal Equivalents.

Binary	Decimal	Hexadecimal	Binary	Decimal	Hexadecimal
0000	0	0	1000	8	8
0001	1	1	1001	9	9
0010	2	2	1010	10	A
0011	3	3	1011	11	B
0100	4	4	1100	12	C
0101	5	5	1101	13	D
0110	6	6	1110	14	E
0111	7	7	1111	15	F

---

---

---

---

---

---

---

---

## Translating Binary to Hexadecimal

- Each hexadecimal digit corresponds to 4 binary bits.
- Example: Translate the binary integer 000101101010011110010100 to hexadecimal:

1	6	A	7	9	4
0001	0110	1010	0111	1001	0100

---

---

---

---

---

---

---

---

## Converting Hexadecimal to Decimal

- Multiply each digit by its corresponding power of 16:  
$$\text{dec} = (D_3 \times 16^3) + (D_2 \times 16^2) + (D_1 \times 16^1) + (D_0 \times 16^0)$$
- Hex 1234 equals  $(1 \times 16^3) + (2 \times 16^2) + (3 \times 16^1) + (4 \times 16^0)$ , or decimal 4,660.
- Hex 3BA4 equals  $(3 \times 16^3) + (11 \times 16^2) + (10 \times 16^1) + (4 \times 16^0)$ , or decimal 15,268.

---

---

---

---

---

---

---

---

## Powers of 16

Used when calculating hexadecimal values up to 8 digits long:

$16^n$	Decimal Value	$16^n$	Decimal Value
$16^0$	1	$16^4$	65,536
$16^1$	16	$16^5$	1,048,576
$16^2$	256	$16^6$	16,777,216
$16^3$	4096	$16^7$	268,435,456

---

---

---

---

---

---

---

---

## Converting Decimal to Hexadecimal

Division	Quotient	Remainder
422 / 16	26	6
26 / 16	1	A
1 / 16	0	1

decimal 422 = 1A6 hexadecimal

---

---

---

---

---

---

---

---

## Hexadecimal Addition

- Divide the sum of two digits by the number base (16). The quotient becomes the carry value, and the remainder is the sum digit.

36	28	<sup>1</sup> 28	<sup>1</sup> 6A
42	45	58	4B
78	6D	80	B5

21 / 16 = 1, rem 5

Important skill: Programmers frequently add and subtract the addresses of variables and instructions.

---

---

---

---

---

---

---

---

## Hexadecimal Subtraction

- When a borrow is required from the digit to the left, add 10h to the current digit's value:

$$\begin{array}{r}
 \text{C6} \\
 \text{A2} \\
 \hline
 24
 \end{array}
 \begin{array}{r}
 75 \\
 47 \\
 \hline
 2\text{E}
 \end{array}$$

$10\text{h} + 5 = 15\text{h}$   
 $\downarrow$   
 $-1$

Practice: The address of **var1** is 00400020. The address of the next variable after var1 is 0040006A. How many bytes are used by var1?

---

---

---

---

---

---

---


---

---

---

## Signed Integers

The highest bit indicates the sign. 1 = negative, 0 = positive



If the highest digit of a hexadecimal integer is > 7, the value is negative. Examples: 8A, C5, A2, 9D

---

---

---

---

---

---

---

---

---

---

## Forming the Two's Complement

- Negative numbers are stored in two's complement notation
- Represents the **additive Inverse**

Starting value	00000001
Step 1: reverse the bits	11111110
Step 2: add 1 to the value from Step 1	11111110 +00000001
Sum: two's complement representation	11111111

Note that 00000001 + 11111111 = 00000000

---

---

---

---

---

---

---

---

---

---

## Binary Subtraction

- When subtracting  $A - B$ , convert B to its two's complement
- Add A to  $(-B)$

$$\begin{array}{r} 00001100 \\ - 00000011 \\ \hline \end{array} \longrightarrow \begin{array}{r} 00001100 \\ + 11111101 \\ \hline 00001001 \end{array}$$

Practice: Subtract 0101 from 1001.

## Learn How To Do the Following:

- Form the two's complement of a hexadecimal integer
- Convert signed binary to decimal
- Convert signed decimal to binary
- Convert signed decimal to hexadecimal
- Convert signed hexadecimal to decimal

## Ranges of Signed Integers

The highest bit is reserved for the sign. This limits the range:

Storage Type	Range (low-high)	Powers of 2
Signed byte	-128 to +127	$-2^7$ to $(2^7 - 1)$
Signed word	-32,768 to +32,767	$-2^{15}$ to $(2^{15} - 1)$
Signed doubleword	-2,147,483,648 to 2,147,483,647	$-2^{31}$ to $(2^{31} - 1)$
Signed quadword	-9,223,372,036,854,775,808 to +9,223,372,036,854,775,807	$-2^{63}$ to $(2^{63} - 1)$

Practice: What is the largest positive value that may be stored in 20 bits?

## Character Storage

- Character sets
  - Standard ASCII (0 – 127)
  - Extended ASCII (0 – 255)
  - ANSI (0 – 255)
  - Unicode (0 – 65,535)
- Null-terminated String
  - Array of characters followed by a *null byte*
- Using the ASCII table
  - back inside cover of book

---

---

---

---

---

---

---

---

## Numeric Data Representation

- pure binary
  - can be calculated directly
- ASCII binary
  - string of digits: "01010101"
- ASCII decimal
  - string of digits: "65"
- ASCII hexadecimal
  - string of digits: "9C"

next: Boolean Operations

---

---

---

---

---

---

---

---

## Boolean Operations

- NOT
- AND
- OR
- Operator Precedence
- Truth Tables

---

---

---

---

---

---

---

---

## Boolean Algebra

- Based on **symbolic logic**, designed by George Boole
- Boolean expressions created from:
  - NOT, AND, OR

Expression	Description
$\neg X$	NOT X
$X \wedge Y$	X AND Y
$X \vee Y$	X OR Y
$\neg X \vee Y$	( NOT X ) OR Y
$\neg(X \wedge Y)$	NOT ( X AND Y )
$X \wedge \neg Y$	X AND ( NOT Y )

Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

40

---

---

---

---

---

---

---


---

## NOT

- Inverts (reverses) a boolean value
- Truth table for Boolean NOT operator:

X	$\neg X$
F	T
T	F

Digital gate diagram for NOT:



Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

41

---

---

---

---

---

---

---


---

## AND

- Truth table for Boolean AND operator:

X	Y	$X \wedge Y$
F	F	F
F	T	F
T	F	F
T	T	T

Digital gate diagram for AND:



Irvine, Kip R. Assembly Language for Intel-Based Computers, 2003. [Web site](#) [Examples](#)

42

---

---

---

---

---

---

---


---

## OR

- Truth table for Boolean OR operator:

X	Y	$X \vee Y$
F	F	F
F	T	T
T	F	T
T	T	T

Digital gate diagram for OR:




---

---

---

---

---

---

---

---

## Operator Precedence

- Examples showing the order of operations:

Expression	Order of Operations
$\neg X \vee Y$	NOT, then OR
$\neg(X \vee Y)$	OR, then NOT
$X \vee (Y \wedge Z)$	AND, then OR

---

---

---

---

---

---

---

---

## Truth Tables (1 of 3)

- A **Boolean function** has one or more Boolean inputs, and returns a single Boolean output.
- A **truth table** shows all the inputs and outputs of a Boolean function

Example:  $\neg X \vee Y$

X	$\neg X$	Y	$\neg X \vee Y$
F	T	F	T
F	T	T	T
T	F	F	F
T	F	T	T

---

---

---

---

---

---

---

---

## Truth Tables (2 of 3)

- Example:  $X \wedge \neg Y$

X	Y	$\neg Y$	$X \wedge \neg Y$
F	F	T	F
F	T	F	F
T	F	T	T
T	T	F	F

---

---

---

---

---

---


---

---

## Truth Tables (3 of 3)

- Example:  $(Y \wedge S) \vee (X \wedge \neg S)$

X	Y	S	$Y \wedge S$	$\neg S$	$X \wedge \neg S$	$(Y \wedge S) \vee (X \wedge \neg S)$
F	F	F	F	T	F	F
F	T	F	F	T	F	F
T	F	F	F	T	T	T
T	T	F	F	T	T	T
F	F	T	F	F	F	F
F	T	T	T	F	F	T
T	F	T	F	F	F	F
T	T	T	T	F	F	T



Two-input multiplexer

---

---

---

---

---

---

---

---



54 68 65 20 45 6E 64

What do these numbers represent?

---

---

---

---

---

---

---

---